



ATTENTION:

In order to activate the Inertial pack you must check in the System Info menu that your Corsaro has version 2.85 or later Firmware, it is still recommended to keep it updated to the latest firmware version available at the following link:


<http://www.starlane.com/vedit/15/firmware-software-digirace-DOWNLOAD.asp?pagina=1659&Sfirmware=1>

Before proceeding it is advisable to download, through the DigiRaceMMX software, the existing sessions that you would like to keep.

To activate the Inertial Pack you must install the free DigiraceMMX software available on the site at the following link and configure the Bluetooth connection as indicated on the manual:


<http://www.starlane.com/vedit/15/firmware-software-digirace-DOWNLOAD.asp?pagina=1659&Ssoftware=1>

After configuring the connection, turn on Corsaro and read the activation code of the Interactive Pack as shown in the image.



Save the generated activation file to your PC desktop and send it to the server via the upgrade link you can find on Starlane website www.starlane.com

Once you have paid and completed the procedure you will receive an email with the .SLF extension file you will need to send to Corsaro via the send command as follows:



Once the license file is sent, the Inertial Pack will be immediately active on your Corsaro.